



**RANDALL'S**  
DECOR SINCE 1948

**ORLEANS:**  
2003 St Joseph Blvd  
Orléans, ON K1C 1E5  
613 824-2438

**GLEBE:**  
555 Bank St  
Ottawa, ON K1S 5P7  
613 233-8441

**BELLS CORNERS:**  
2120 Robertson Rd  
Nepean, ON K2H 5Z1  
613 828-2303

**02**  
**INFO PAGE**

## EXTERIOR WINDOW SILLS

### STEP 1

Remove all loose paint, ensure there is no rot present and clean thoroughly (TSP).  
(if rotten wood exists use PC Petrifier and PC Woody to repair it or replace wood).

### STEP 2

- a) When surface is completely dry, prime all bare wood with a long-oil primer (C2-ALA9100). Let dry for 24 hrs.
- b) Caulk all cracks and crevices (especially on the horizontal surfaces) thoroughly with latex acrylic caulking to ensure water can not penetrate wood.

### STEP 3

Apply 2 coats of top quality exterior latex acrylic paint (C2 DTS Satin, C2 Eggshell exterior latex).

### Note:

Peeling problems normally occur on the window sills and about 6 inches up each side of the window (the upper parts of the window frame rarely peel). This is because water tends to sit on the horizontal surfaces and will penetrate into the wood if there are any cracks, crevices or exposed wood.

Make sure your windowsill has a slight slope and sheds water away from the window properly. The recipe above will yield the best results possible on just about any horizontal surface to be painted.